---- Written Code-----

Installing Samba

To install it on your Ubuntu system follow the steps below:

1) Start by updating the apt packages index:

```
sudo apt update
```

2) Install the Samba package with the following command:

```
sudo apt install samba
```

3) Once the installation is completed, the Samba service will start automatically. To check whether the Samba server is running, type:

```
sudo systemctl status smbd
```

4) The output should look something like below indicating that Samba service is active and running:

```
`• smbd.service - Samba SMB Daemon
```

Loaded: loaded (/lib/systemd/system/smbd.service; enabled; vendor preset: enabled)
Active: active (running) since Wed 2022-04-16 09:25:38 UTC; 2min 12s ago Docs:
man:smbd(8) man:samba(7) man:smb.conf(5) Main PID: 15142 (smbd) Status: "smbd: ready
to serve connections..." Tasks: 4 (limit: 1152) CGroup: /system.slice/smbd.service
...`

Configuring firewall

Assuming you are using [UFW] to manage your firewall, you can open the ports by enabling the 'Samba' profile:

1) install UFW

sudo apt install ufw sudo ufw allow 'Samba'

Configuring Global Samba Options

The default configuration file that ships with the Samba package is configured for standalone Samba server.

1) Open the file and make sure server role is set to standalone server

```
`sudo nano /etc/samba/smb.conf`
```

2) Enable and Restart the Samba services with:

```
systemctl enable smbd.service
sudo systemctl restart smbd
systemctl enable nmbd.service
sudo systemctl restart nmbd
```

Creating Samba Users and DS

1) To create the /samba directory type:

```
`sudo mkdir /samba`
```

2) Set the group ownership to sambashare. This group is created during the Samba installation, later we will add all Samba users to this group

```
`sudo chgrp sambashare /samba`
```

Creating Samba Users

1) To create a new user named josh use the following command: sudo useradd -M -d /samba/josh -s /usr/sbin/nologin -G sambashare josh 2) Create the user's home directory and set the directory ownership to user josh and group sambashare:

```
sudo mkdir /samba/josh
sudo chown josh:sambashare /samba/josh
```

3) The following command will add the setgid bit to the /samba/josh directory so the newly created files in this directory will inherit the group of the parent directory.

```
`sudo chmod 2770 /samba/josh`
```

4) Add the josh user account to the Samba database by setting the user password:

```
sudo smbpasswd -a josh
```

5) You will be prompted to enter and confirm the user password. Once the password is set to enable the Samba account run:

```
sudo smbpasswd -e josh
```

Configuring Samba Shares

1) Open the Samba configuration file and append the sections:

```
sudo nano /etc/samba/smb.conf
```

```
[josh]
  path = /samba/josh
  browseable = yes
  read only = no
  force create mode = 0660
```

```
force directory mode = 2770
valid users = josh @sadmin
```

2) Once done run the testparm utility to check the Samba configuration file for errors. If there are no syntax errors you will see Loaded services file ok

```
` testparm `
```

3) Once done, restart the Samba services with:

```
sudo systemctl restart smbd
sudo systemctl restart nmbd
```

Using the smbclient client

1) To install smbclient on Ubuntu and Debian run:

```
sudo apt install smbclient
```

2) For example to connect to a share named josh on a Samba server with IP address 192.168.121.118 as user josh you would run:

```
smbclient //192.168.121.118/josh -U josh
```

3) You will be prompted to enter the user password so enter it.